

### **CODE NUMBER**

3783201

### **DESCRIPTION**

1.5 gpf, Rough Brass Finish, Single Flush, 1" Straight Control Stop, 9.75 L Dimension, Sloan® Concealed Manual Urinal Flushometer.

#### DETAILS

Flush Volume: 1.5 gpf (5.7 Lpf)Finish: Rough Brass (RB)

· Valve: Diaphragm

• Valve Body Material: Semi-red Brass

• Fixture Type: Urinal

Fixture Connection: Rear spud
Rough-In Dimension: 13 ½" (343mm)

Spud Coupling: ¾" (19mm)
Supply Pipe: ¾" (19mm)

• L Dimension: 9 3/4" (248mm) (9-3/4-LDIM)

• Control Stop: 1" Straight (E)

### **FEATURES**

- Flush volumes start as low as 1.0 gpf/3.8 Lpf
- Water conservation is aided by the ADA-compliant, non-hold-open handle, which prevents urinal from exceeding intended flush volume
- Low-consumption flush accuracy also enhances water efficiency
- Durability is facilitated with high copper, low zinc brass castings for dezincification resistance
- Adjustable tailpiece to accommodate different height requirements
- High chloramine resistant PERMEX synthetic rubber diaphragm with Linear Filtered Bypass and Vortex Cleansing Action
- Valve body, Cover, Tailpiece and Control Stop shall be in compliance with ASTM Alloy Classification for Semi-Red Brass
- Valve shall be in compliance to the applicable sections of ASSE 1037.



### **COMPLIANCES & CERTIFICATIONS**







(ADA Compliant, cUPC Certified, BAA Compliant)

### RECOMMENDED SPECIFICATION

Valve Body, Cover, Tailpiece and Control Stop shall be in conformance with ASTM Alloy Classification for Semi- Red Brass. Valve shall be in compliance with the applicable sections of ASSE 1037 and ANSI/ASME 112.19.2.

### VALVE OPERATING PRESSURE (FLOWING)

15–80 PSI (103–552 kPa). Specific fixtures may require greater minimum flowing pressure - consult manufacturer requirements.

### **DOWNLOADS**

- Sloan Concealed Installation Instructions
- Control Stop Repair and Maintenance Guide
- Flush Connections Flanges Repair and Maintenance Guide
- Tail Piece Repair and Maintenance Guide
- Additional Downloads

# NOTES

All information contained within this document subject to change without notice.

Looking for other variations of the SLOAN 195 product? View the general spec sheet with all options.

Find a compatible urinal for this flushometer.
Find a compatible water closet for this flushometer.

Phone: 800.982.5839 • Fax: 800.447.8329 • sloan.com



## **ROUGH-IN**

