

SEE POWER SUPPLY INSTALLATION INSTRUCTIONS FOR INSTALLING POWER SUPPLY

1. Rod and lens must be 3/8" shorter than closet width measurement.
2. If field-trimming is necessary, slide lens out of fixture. Use scissors or shears to trim lens to length (3/8" shorter than closet width.)
3. Use chop or hacksaw to cut rod to proper length. DO NOT CUT LED CIRCUIT BOARD. Deburr all cut edges. Slide lens back into place.
4. Prep wires for LED fixture: Strip 1/4" of insulation from RED and BLACK wires.

8. Insert "non-wired" side of rod into installed flange.



5. Using #8 (1 1/2") wood screws provided, secure one flange to wall stud on "non-wired" side of closet.



9. Partially fasten second flange to wall using **ONE** screw. Carefully position wires into one of the grooves located on back of flange. Secure flange to wall with remaining screw, making sure wire is in flange groove. (If wires come through drywall and into the fixture, this step is not needed.)



6. Slide second flange onto rod with grooved side facing opposite wall.



10. Push rod against wall in "non-wired" flange and tighten set screw.

7. Holding rod, lens, and loose flange in one hand, push RED solid wire push straight into LED terminal block opening with RED mark. Push BLACK solid wire straight into terminal with BLACK mark. (20/2 solid wire is recommended. If using 20/2 stranded wire, ends must be tinned. Depress terminal block tab with ball point pen and insert wire.)

11. Cut Sempria WireWay to cover wires from flange exit to driver. Remove cover of WireWay and secure mounting base (wider piece) to wall with screws provided. Position wires inside base and snap cover (smaller piece) into place. Deburr all cut WireWay edges to protect wire insulation.



NOTE: Maintain wire polarity. If fixture does not illuminate after making wire connections, reverse wires at driver. (A slight delay "on" is possible.)